
EXIT
F1
F2
F3
F4
F5
F6
F7
F8
MENU
QUIT
PTR
STOP
← DEL
TAB
RETURN
CAPS LOCK
SHIFT
SHIFT
EXTRA
ALT
EXTRA
ALT
EXTRA
MENU
EXTRA
CUT
COPY
PASTE
DEL→
CAN
DOC PAGE
NUM LOCK
PTR
LINE EOL
WORD CHAR
FIND EXCH
UNIT PARA
RELAY
CAN
ENTER
These two keys can be swapped.
These two keys can be swapped.